

230  
T. 60

L & M Supplement to

# MONARCH ELECTRIC RANGE PARTS CATALOG

+ +

Effective April 1, 1939

+ +

Parts for L & M Series Monarch Electric Ranges

Prices in this catalog supersede all previous prices and are subject to change without notice.

All prices F. O. B. shipping point.

When ordering, specify model number and serial number of range.

+ +

**MALLEABLE IRON RANGE COMPANY**  
Beaver Dam, Wisconsin

I N D E X

Range No.	Page
36L and 16L . . . . .	1
46L . . . . .	2
56L . . . . .	3
66L . . . . .	4
37L with 2V Serial No. and 17L . . . . .	5-6
57L and C57L . . . . .	6-7
47L and C47L . . . . .	7-8
H47L . . . . .	8-9-10-11
96L, 96LX and H96L . . . . .	11-12
16M . . . . .	12-13
17M . . . . .	13-14
46M . . . . .	14-15
56M . . . . .	15-16
57M . . . . .	17-18
73L . . . . .	18
H47M . . . . .	19-20
H46M . . . . .	20-21

MISCELLANEOUS ELECTRICAL PARTS

Surface Units, Open Coil Type . . . . .	22
Monarch Chromalox Closed Units . . . . .	23
Oven Units, Switches, Oven Temperature Controls . . . . .	24
Cookers, Sauce Pan, Plate Warming Units . . . . .	25
Miscellaneous Parts . . . . .	26
Includes: Timer Receptacles, Lamps, Shelves, Condiment Sets, Timers and Notifiers.	

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 36L and 16L

Part No.	Description	List Price
(Electrical Parts)		
R19BB	1000 watt surface unit complete . . . . .	\$ 5.00
R158BB	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R271	Oven unit, bottom, 1500 watts, complete . . . . .	8.70
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R271 oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R261	Oven temperature control, complete . . . . .	22.50
R145	Appliance receptacle . . . . .	1.50

(For additional and detailed electrical parts see)  
(pages 22 - 26. )

(Enameled Parts)

E2542	Cooking top for 16L . . . . .	14.00
AE562	Cooking top for 36L . . . . .	13.00
E2543	Switch panel for 16L . . . . .	7.00
E2501	Switch panel for 36L . . . . .	7.00
E2504R	Body side, right . . . . .	10.00
E2504L	Body side, left . . . . .	10.00
AE561-1	Splasher . . . . .	4.50
E1903	Oven door panel . . . . .	4.50
E2316-1	Oven door lining . . . . .	3.00
E2505	Oven lining . . . . .	10.00
E791R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E2506	Compartment door panel . . . . .	3.70
E2502	Lower front panel . . . . .	4.50
E2513	Drip pan . . . . .	1.75
E1242-1	Brace for splasher, each . . . . .	.30

(Miscellaneous Parts)

9140R&L	Spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2517	Hinge rod for oven and compartment door . . . . .	1.00
AE197-4	Vent shield . . . . .	1.00
6606B	Oven door handle . . . . .	1.50
6606B	Compartment door handle . . . . .	1.50
E2507	Shelf for supporting cooker . . . . .	1.25
E2519R	Slide for supporting cooker shelf, right . . . . .	.40
E2520L	Slide for supporting cooker shelf, left . . . . .	.40
3655	Catch for compartment door . . . . .	.30
3655B	Strike for compartment door . . . . .	.30
E2723	Sash chain for compartment door . . . . .	.40
E2534-1	Base complete . . . . .	4.50
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 46L.

Part No.	Description	List Price
(Electrical Parts)		
R248BC	1000 watt surface unit complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R139	Oven unit, bottom, 1500 watts, complete . . . . .	8.70
R98 <sup>3</sup> / <sub>4</sub>	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R139 oven unit . . . . .	1.30
R252	Heating wires only for R98 <sup>3</sup> / <sub>4</sub> broiler unit . . . . .	1.50
R261	Oven temperature control complete . . . . .	22.50
R240	Appliance receptacle . . . . .	1.20

(For additional and detailed electrical parts)  
(see pages 22 - 26.)

(Enameled Parts)

E2442	Cooking top . . . . .	20.00
E2443-1	Switch Panel . . . . .	7.00
E2303	Body side, left . . . . .	10.00
E2304	Body side, right . . . . .	10.00
E2405	Vertical front strip . . . . .	2.00
E2441	Splasher . . . . .	7.00
E1903	Oven Door Panel . . . . .	4.50
E2316	Oven Door lining . . . . .	3.00
E2410R	Oven lining . . . . .	10.00
E791R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E2305	Front panel for utensil drawer . . . . .	4.50
E2330	Utensil drawer, less front panel . . . . .	4.50
E2063	Drip pan . . . . .	2.00
251ER-1	Vent cap grill, each . . . . .	.50

(Miscellaneous Parts)

6606B	Handles for doors, each . . . . .	1.50
9140R&L	Spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2368	Hinge rod for oven door . . . . .	.30
W2	Spring catch for oven door . . . . .	.10
E2422	Guides for utensil drawers, pair . . . . .	1.00
AG22	Rails for utensil drawer, pair . . . . .	1.00
E2453	Base complete . . . . .	5.00
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 56L.

Part No.	Description	List Price
(Electrical Parts)		
R248BC	1000 watt surface unit complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R139	Oven unit, bottom, 1500 watt, complete . . . . .	8.70
R98 $\frac{3}{4}$	Broiler unit, 1925 watt, complete . . . . .	7.50
R104	Heating wires only for R139 oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R260	Oven temperature control complete . . . . .	22.50
R266	Appliance receptacle. . . . .	1.70
R237	Plate warmer unit, complete . . . . .	10.00
R182	Toggle switch for plate warmer unit . . . . .	1.00

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2442	Cooking top . . . . .	20.00
E1914	Switch Panel . . . . .	3.50
E2303	Body side, left . . . . .	10.00
E2304	Body side, right . . . . .	10.00
E2405	Vertical front strip . . . . .	2.00
E2441	Splasher . . . . .	7.00
E1903	Oven Door Panel . . . . .	4.50
E2316	Oven Door lining . . . . .	3.00
E2410R	Oven lining . . . . .	10.00
E791R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E2305	Front panel for large utensil or plate warmer drawer . . . . .	4.50
E2330	Large utensil drawer, less front panel . . . . .	4.50
E2328	Plate warmer drawer, less front panel . . . . .	5.00
E1909	Front panel for small utensil drawer . . . . .	3.50
E2092	Small utensil drawer less front panel . . . . .	3.50
E2063	Drip pan . . . . .	2.00
E251ER-1	Vent cap grill, each . . . . .	.50

(Miscellaneous Parts)

6606B	Handles for doors, each . . . . .	1.50
9140R&L	Spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2368	Hinge rod for oven door . . . . .	.30
A2	Spring catch for oven door . . . . .	.10
E2422	Guides for utensil drawers, pair . . . . .	1.00
E2461	Guides for plate warmer drawers, pair . . . . .	1.00
A622	Rails for utensil drawers, pair . . . . .	1.00
A622	Rails for plate warmer drawer, pair . . . . .	1.00
E2453	Base complete . . . . .	5.00
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 66L.

Part No.	Description	List Price
(Electrical Parts)		
R248BB	1000 watt surface unit, complete, 6 $\frac{1}{2}$ " . . . . .	\$ 5.00
R19BB	1000 watt surface unit, complete, 9" . . . . .	5.00
R158BB	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R139	Oven unit, bottom, 1500 watts, complete . . . . .	8.70
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R139 oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R260	Oven temperature control complete . . . . .	22.50
R240	Appliance receptacle . . . . .	1.20

(For additional and detailed electrical parts see)  
(pages 22 - 26. )

(Enameled Parts)

E2676	Cooking top . . . . .	22.50
E2677-1	Switch Panel . . . . .	7.00
E2303	Body side, left . . . . .	10.00
E2678	Body side, right . . . . .	10.00
E2679	Vertical front strip . . . . .	2.00
E2441	Splasher . . . . .	7.00
E1903	Oven Door Panel . . . . .	4.50
E2316	Oven Door lining . . . . .	3.00
E2410R	Oven Lining . . . . .	10.00
E791R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler Pan, less rack . . . . .	2.10
E2305	Front Panel for upper utensil drawer . . . . .	4.50
E2370	Upper utensil drawer, less front panel . . . . .	4.50
E1905	Front panel for lower utensil drawer, each . . . . .	3.50
E2092	Lower utensil drawer, less front panel, each . . . . .	3.50
E2338-1	Drip pan . . . . .	2.00
251ER-1	Vent cap grill, each . . . . .	.50

(Miscellaneous Parts)

6606B	Handles for doors, each . . . . .	1.50
E2422	Guides for upper drawers, pair . . . . .	1.00
E2687	Guides for lower drawers, pair . . . . .	1.00
9140R&L	Spring assembly for oven door complete, each . . . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2368	Hinge rod for oven door . . . . .	.30
W2	Spring catch for oven door . . . . .	.10
E2453	Base complete . . . . .	5.00
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 37L WITH 2V SERIAL NUMBERS and 17L

Part No.	Description	List Price
(Electrical Parts)		
R248BB	1000 watt surface unit complete for 17L . . . . .	\$ 5.00
R19BB	1000 watt surface unit complete for 37L . . . . .	5.00
R158BB	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for Oven units . . . . .	2.50
R260	Oven temperature control, complete . . . . .	22.50
R218	Oven unit, bottom, 1500 watts complete . . . . .	8.50
R217	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R218 oven unit . . . . .	1.30
R252	Heating wires only for R217 broiler unit . . . . .	1.50
R266	Appliance receptacle (28X93) . . . . .	1.70

(For additional and detailed electrical parts see)  
(pages 22 - 26. )

(Enameled Parts)

E2724	Cooking top for 37L . . . . .	15.50
E1102-1	Cooking top for 17L . . . . .	13.50
E2701	Switch panel for 37L . . . . .	5.00
E2725	Switch panel for 17L . . . . .	5.00
E2702	Body side, right . . . . .	10.00
E2703	Body side, left . . . . .	10.00
E1101-1	Splasher . . . . .	5.50
E2255	Oven door panel . . . . .	6.00
E2259	Oven door lining . . . . .	4.00
E1865	Oven lining . . . . .	10.00
E791R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan less rack . . . . .	2.10
E2605	Compartment door panel . . . . .	4.00
E2603	Lower front panel . . . . .	5.00
E1242-1	Brace for splasher, each . . . . .	.30
E2704	Shelf for supporting cooker . . . . .	1.50
E2610	Drip pan . . . . .	1.75
E2709	Front frame with hinges for compartment, black porcelain . . . . .	3.50
E2606R	Front frame for oven, black porcelain . . . . .	5.00

To order porcelain parts for 37L ranges  
with V serial numbers refer to 37K parts  
list in K catalog.

(Miscellaneous Parts)

E2720	Base Complete . . . . .	5.00
AE197-4	Vent Shield . . . . .	1.00
5651	Compartment door handle . . . . .	1.50
5651	Oven door handle . . . . .	1.50
82	Roller type spring catch for oven door . . . . .	.10

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 37L WITH 2V SERIAL NUMBERS  
and 17L--Continued

Part No.	Description	List Price
(Miscellaneous Parts -- Continued)		
2251R&L	Oven Door hinge, each . . . . .	\$.30
E2281	Hinge rod for oven door . . . . .	.30
E2640	Hinge rod for compartment door . . . . .	.75
E2636	Stake arm assembly for oven door, each . . . . .	.30
3655	Catch for compartment door . . . . .	.30
3655B	Strike for compartment door . . . . .	.30
E2713	Slides for Cooker, each . . . . .	.40
E2723	Sash chain for compartment door . . . . .	.40
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 57L and C57L

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit, complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R100 $\frac{3}{4}$	Oven unit, bottom, 1500 watts, complete . . . . .	8.50
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R100 $\frac{3}{4}$ oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R259	Oven temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70
R260	Roaster temperature control, complete . . . . .	22.50
R265	Switch for roaster . . . . .	.90
R244	Roaster complete with cover, insets, and temperature control . . . . .	49.50

(For additional and detailed electrical parts)  
(see pages 22 - 26.)

(Enameled Parts)

E1676	Cooking top . . . . .	15.00
E1677	Cover on cooking top over roaster . . . . .	4.00
	Cover, white, for roaster pan . . . . .	1.00
	Seal rim, black porcelain . . . . .	1.00
E2651	Splasher . . . . .	7.50
E2652-1	Switch panel . . . . .	5.50
E2602L	Body side, left . . . . .	10.00
E2602R	Body side, right . . . . .	10.00
E2255	Oven door panel . . . . .	6.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 57L and C57L--Continued

Part No.	Description	List Price
(Enameled Parts -- Continued)		
E2259	Oven door lining . . . . .	\$ 4.50
E2645	Oven lining . . . . .	11.00
E791R&L	Rack slides for oven, each . . . . .	2.20
AE160	Broiler pan, less rack . . . . .	2.10
E2603	Lower front panel . . . . .	6.00
E2605	Compartment door panel . . . . .	5.00
E2656	Drip tray . . . . .	2.00
E264	Roaster pan, black . . . . .	5.00

(Miscellaneous Parts)

6651	Oven door handle . . . . .	1.50
6651	Compartment door handle . . . . .	1.50
E2621-1	Lining for compartment door . . . . .	1.50
E2628	Base . . . . .	5.00
E2636	Stake arm assembly for oven door, each . . . . .	.30
E2251R&L	Hinge for oven door, each . . . . .	.50
E2281	Hinge rod for oven door . . . . .	.30
W2	Roller spring catch for oven door . . . . .	.10
E2632R&L	Hinge for compartment door, each . . . . .	.30
AG107-1	Stake arm for compartment door . . . . .	.30
E2640	Hinge rod for compartment door . . . . .	.25
3655B	Strike for compartment door . . . . .	.20
3655	Catch on compartment door . . . . .	.20
	Spring on compartment door . . . . .	.30
	Leaf spring assembly for oven door . . . . .	1.75
	Chrome strips for splasher, set of 3 . . . . .	1.50
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 47L and C47L

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R100 $\frac{3}{4}$	Oven unit, bottom, 1500 watts, complete . . . . .	8.50
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50
R104	Heating wires only for R100 $\frac{3}{4}$ oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R259	Oven Temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70

(For additional and detailed electrical parts see)  
(pages 22 - 26. )

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 47L and C47L--Continued

Part No.	Description	List Price
(Enameled Parts)		
E2604	Switch Panel . . . . .	\$ 5.50
E2602L	Body side, left . . . . .	10.00
E2602R	Body side, right . . . . .	10.00
E2255	Oven door panel . . . . .	6.00
E2259	Oven door lining . . . . .	4.50
E2645	Oven lining . . . . .	11.00
E2606L	Oven front frame, black . . . . .	6.50
E2605	Compartment door panel . . . . .	5.00
E2603	Lower front panel . . . . .	6.00
E1333	Cooking top . . . . .	14.00
E2601	Splasher . . . . .	7.50
AE160	Broiler pan, less rack . . . . .	2.10
E791R&L	Rack slides for oven, each . . . . .	2.20
E2610	Drip tray . . . . .	1.75

(Miscellaneous Parts)

E2629	Base complete . . . . .	5.00
6651	Oven door handle . . . . .	1.50
6651	Compartment door handle . . . . .	1.50
E2626	Drip tray slides, each . . . . .	.40
E2621	Compartment door lining . . . . .	2.00
E2636	Stake arm assembly for oven door, each . . . . .	.30
E2251R&L	Hinge for oven door, each . . . . .	.20
E2281	Hinge rod for oven door . . . . .	.30
W2	Roller spring catch for oven door . . . . .	.10
E2632R&L	Hinge for compartment door, each . . . . .	.30
AG107-1	Stake arm for compartment door . . . . .	.30
E2640	Hinge rod for compartment door . . . . .	.25
3655B	Strike for compartment door . . . . .	.20
3655	Catch on compartment door . . . . .	.20
	Spring for compartment door . . . . .	.30
	Leaf spring assembly for oven door . . . . .	1.25
260ER	Shelf for Timer . . . . .	4.60
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50
	Chrome strips for splasher, set of 3 . . . . .	1.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47L

Part No.	Description	List Price
(Electrical Parts)		
R19BB	1000 watt surface unit complete . . . . .	\$ 5.00
R158BB	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R100 $\frac{3}{4}$	Oven unit, bottom, 1500 watts, complete . . . . .	8.50
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47L--Continued

Part No.	Description	List Price
(Electrical Parts -- Continued)		
R104	Heating wires only for R100 <sup>3</sup> / <sub>4</sub> oven unit . . . . .	\$ 1.30
R252	Heating wires only for R98 <sup>3</sup> / <sub>4</sub> broiler unit . . . . .	1.50
R260	Oven temperature control, complete . . . . .	22.50
R145	Appliance receptacle . . . . .	1.50

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts to W487 Serial Numbers)

E1301-2	Cooking top . . . . .	14.00
E1101-2	Splasher . . . . .	5.50
E1807	Switch panel . . . . .	3.50
E1303	Body side, left . . . . .	7.00
E1804	Body side, right . . . . .	7.00
E1851	Oven door panel . . . . .	6.00
E1805	Front panel on fire door . . . . .	7.00
E1306	Lining for fire door . . . . .	3.00
E1163-1L	Oven lining . . . . .	11.00
E1852	Oven door lining . . . . .	4.50
E791R&L	Rack slides for oven, each . . . . .	2.20
AE160	Broiler pan, less rack . . . . .	2.10
E1813	Drip tray, less front strip . . . . .	2.00

(Base Parts for H47L - to W487 Serial Number)

E1833	Front upper base strip, white . . . . .	4.50
E1707	Front lower base strip, black . . . . .	2.00
E1834L	End, left side . . . . .	4.00
E1834R	End, right side . . . . .	4.00
E1708	Corner post, black . . . . .	1.00

(Base complete for H47L - after Serial W487)  
(see Miscellaneous Parts. )

(Enameled Parts after W487 Serial Numbers)

E1301-2	Cooking top. . . . .	14.00
E1101-2	Splasher . . . . .	5.50
E2801	Switch panel . . . . .	3.50
E2802L	Body side, left . . . . .	7.00
E2802R	Body side, right . . . . .	7.00
G1989	Oven door panel . . . . .	6.00
G1981	Oven door lining . . . . .	4.50
E1163-1L	Oven lining . . . . .	11.00
E791R&L	Rack slides for oven, each . . . . .	2.20
AE160	Broiler pan, less rack . . . . .	2.10
E1805	Front panel on fire door . . . . .	7.00
E1306	Lining for fire door . . . . .	3.00
E2803	Lower front panel . . . . .	5.00
	Drip tray less front strip . . . . .	2.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47L--Continued

Part No.	Description	List Price
(Firebox Parts)		
252ER	Front section, left side firebox lining . . . . .	\$ 1.00
253ER	Center section, left side firebox lining . . . . .	1.90
254ER	Rear section, left side firebox lining . . . . .	1.10
255ER	Front section, right side firebox lining . . . . .	1.10
253ER	Center section, right side firebox lining . . . . .	1.90
256ER	Rear section, right side firebox lining . . . . .	1.30
32M	Rear end lining for range with cast iron side linings and less waterfront . . . . .	1.10
32M-1	Rear end lining for range with cast iron side linings and with waterfront . . . . .	1.10
M1 LA	Firebrick lining, left front of firebox . . . . .	1.80
M1 RA	Firebrick lining, right front of firebox . . . . .	1.80
M2 RB	Firebrick lining, right back of firebox . . . . .	1.80
M2 LB	Firebrick lining, left back of firebox . . . . .	1.80
647GR	Rear end lining for range with firebricks and less waterfront . . . . .	1.00
648GR	Rear end lining for range with firebricks and with waterfront . . . . .	1.10
6B	Grate bar, long . . . . .	1.50
7B	Grate bar, short . . . . .	1.40
121D	Grate bar, long, for hard coal firebox . . . . .	1.40
122D	Grate bar, short, for hard coal firebox . . . . .	1.40
	Cogs, each. . . . .	.20
10G	Grate frame . . . . .	1.60
29D	Lid . . . . .	.90
4-30E	Short center . . . . .	1.10
68E	Anchor plate . . . . .	1.80
103D	Front end firebox lining . . . . .	.80
105½D	Cog shed . . . . .	.15
20E	Clean-out door with handle . . . . .	.60
CE74-1	Back flue, steel shell only . . . . .	3.00
CE76-1	Division sheet in back flue . . . . .	1.00
90	Ash pan . . . . .	1.50
665GR	Fire door casting . . . . .	1.00
664GR	Frame for fire door casting . . . . .	.80
654GR	Flue damper complete with frame . . . . .	1.00
239ER	Frame for slide draft . . . . .	.50
240ER	Slide for draft only . . . . .	.50
E1491	Handle for draft slide . . . . .	.40

(Miscellaneous Parts)

6651	Oven door handle, black . . . . .	1.50
6547	Fire door handle . . . . .	.40
E1814	Drip tray, front strip only . . . . .	1.50
AE197-4	Vent shield for oven . . . . .	1.00
E1889	Flat springs for oven door, each to serial W487 . .	.30
4984	Hinge for oven door, each, to Serial W487 . . . . .	.50
G1986	Hinge for oven door, each, after Serial W487 . . .	.30
	Coil spring for oven door, each, to Serial W487 . .	.30

LIST PRICE OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47L--Continued

Part No.	Description	List Price
(Miscellaneous Parts -- Continued)		
	Wire oven rack . . . . .	\$ .85
	Wire broiler pan rack . . . . .	.50
E2822	Base complete . . . . .	5.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 96L, 96LX and H96L

Part No.	Description	List Price
(Electrical Parts)		
R248BB	1000 watt surface unit complete . . . . .	5.00
R158BB	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R98 $\frac{3}{4}$	Broiler unit, 1925 watt, complete . . . . .	7.50
R139	Oven unit, bottom, 1500 watt, complete . . . . .	8.70
R104	Heating wires only for R139 oven unit . . . . .	1.30
R252	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R260	Oven temperature control, complete . . . . .	22.50
R266	Appliance Receptacle . . . . .	1.70

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2442	Cooking top, 96L & 96LX . . . . .	20.00
E2401	Cooking top, H96L . . . . .	22.00
E1913	Switch Panel, 96L . . . . .	3.50
E2174	Switch Panel, 96LX . . . . .	7.00
HE355	Switch Panel, H96L . . . . .	3.50
E2152	Body side, left, 96L & 96LX . . . . .	5.00
HE352	Body side, left, H96L . . . . .	5.00
E2152	Body side, right, 96L and 96LX . . . . .	5.00
E2153	Vertical front strip between switch panel and oven . . . . .	2.00
HE354	Vertical front strip right of firebox, H96L . . . . .	2.00
E2151	Splasher, 96L and 96LX . . . . .	5.00
HE351	Splasher, H96L . . . . .	7.00
E1903	Oven Door Panel . . . . .	4.50
E2316	Oven Door Lining . . . . .	3.00
E2410R	Oven Lining . . . . .	10.00
E791R&L	Oven Rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E1909	Front panel for utensil drawer, 96L & H96L . . . . .	3.50
E2162	Utensil drawer less front panel, 96L & H96L . . . . .	3.50
E2063	Drip pan, 96L & H96L . . . . .	2.00
E2063	Drip pan, 96LX . . . . .	2.00
E2177	Left support for drip pan, 96LX . . . . .	.50
E2176	Right support for drip pan, 96LX . . . . .	.50
HE353	Fire door panel, H96L . . . . .	4.00
E2171	Leg . . . . .	4.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODELS 96L, 96LX and H96L--Continued

Part No.	Description	List Price
(Enameled Parts -- Continued)		
E2172	Base strip, 96L & 96LX . . . . .	\$ 3.00
HE356	Base strip, H96L . . . . .	4.00
E1242-1	Brace for splasher, each . . . . .	.30
HE360	Lining for firedoor panel, H96L . . . . .	1.50

(Miscellaneous Parts)

R1363	Handles for doors, each . . . . .	1.50
9140R&L	Spring assembly for oven door, complete, each . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2368	Hinge rod for oven door . . . . .	.30
W2	Spring catch for oven door . . . . .	.10
AG19	Guides for utensil drawer, 96L & H96L, pair . . . .	1.00
AE197-4	Vent shield . . . . .	1.00
	Wire broiler rack . . . . .	.50

(Firebox Parts for Model H96L)

630GR	Side lining, end section, left or right . . . . .	.90
631GR	Side lining, center section, left or right . . . . .	1.80
632GR	Side lining, end section, left or right . . . . .	.90
592GR-1	Rear end lining, for range less waterfront . . . . .	1.20
613GR-1	Rear end lining, for range equipped with waterfront	.60
591GR	Front end lining for range less waterfront . . . . .	1.10
615GR	Front end lining for range equipped with waterfront	.60
10G	Grate frame . . . . .	1.60
6B	Grate bar, long . . . . .	1.50
7B	Grate bar, short . . . . .	1.40
603GR-1	Cleanout door with handle . . . . .	.60
G616-2	Back flue, steel shell only . . . . .	.80
240ER	Slide damper . . . . .	.50
601GR-2	Flue top collar . . . . .	.50
29D	Lid . . . . .	.90
222ER	Anchor plate . . . . .	1.80
4-30E	Short center . . . . .	1.10
HE368	Ash pan . . . . .	1.35
49E	Damper for back flue . . . . .	.35
654GR	Damper frame for back flue . . . . .	1.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 16M.

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit, complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R291	Oven unit, bottom, 2000 watts, complete . . . . .	8.50
R292	Broiler unit, 2400 watts, complete . . . . .	7.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 16M--Continued

Part No.	Description	List Price
(Electrical Parts -- Continued)		
R293	Heating wires only for R291 oven unit . . . . .	\$ 1.50
R294	Heating wires only for R292 broiler unit . . . . .	1.50
R260	Oven temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2901	Cooking top and splasher . . . . .	25.00
E2904	Switch Panel . . . . .	8.00
E2902	Body side, right . . . . .	11.00
E2902	Body side, left . . . . .	11.00
E2903	Oven door panel . . . . .	4.50
E2946	Oven door lining . . . . .	3.00
E2383R	Oven lining . . . . .	10.00
E2470R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E2903	Front panel for utensil drawer . . . . .	4.50
E2924	Utensil drawer less front panel . . . . .	4.50
E2063	Drip pan . . . . .	2.00
E2905	Lower front panel . . . . .	7.50

(Miscellaneous Parts)

E2940	Base complete . . . . .	5.00
6606B	Handle for oven and drawer . . . . .	1.50
E2973R&L	Hinge and spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for E2973 assembly . . . . .	.50
E2347	Hinge rod for oven door . . . . .	.50
E2927	Guides for utensil drawer, pair . . . . .	1.00
AG22	Rails for utensil drawer, pair . . . . .	1.00
	Chrome molding for cooking top . . . . .	3.00
	Chrome strips for splasher, set of 3 . . . . .	1.50
	Wire oven rack . . . . .	1.00
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 17M.

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit, complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R289	Oven unit, bottom, 2000 watts, complete . . . . .	8.50
R290	Broiler unit, 240 watts, complete . . . . .	7.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 17M--Continued

Part No.	Description	List Price
(Electrical Parts--Continued)		
R293	Heating wires only for R289 oven unit . . . . .	\$ 1.50
R294	Heating wires only for R290 broiler unit . . . . .	1.50
R260	Oven temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70

(Enameled Parts)

E2901	Cooking top and splasher . . . . .	25.00
E3052	Switch panel . . . . .	7.00
E3051	Body side, right . . . . .	11.00
E3051	Body side, left . . . . .	11.00
E2255-1	Oven door panel . . . . .	6.00
E2259	Oven door lining . . . . .	4.50
E2483R	Oven lining . . . . .	11.00
E2470R&L	Oven rack slides, each . . . . .	2.20
AE160	Broiler pan, less rack . . . . .	2.10
E3053	Front panel for utensil drawer . . . . .	5.00
E3067	Utensil drawer less front panel . . . . .	4.00
E3072	Drip pan . . . . .	2.00
E3054	Lower front panel . . . . .	7.00

(Miscellaneous Parts)

E2940	Base complete . . . . .	5.00
6651	Handle for oven and utensil drawer . . . . .	1.50
E2973R&L	Hinge and spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for E2973 assembly . . . . .	.50
E2299	Hinge rod for oven door . . . . .	.50
W2	Roller spring catch for oven door . . . . .	.10
E3070	Guides for utensil drawer, pair . . . . .	1.00
AG22	Rails for utensil drawer, pair . . . . .	1.00
	Chrome molding for cooking top . . . . .	3.00
	Chrome strips for splasher, set of 3 . . . . .	1.50
	Wire oven rack . . . . .	1.00
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 46M.

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R291	Oven unit bottom, 2000 watts, complete . . . . .	8.50
R292	Broiler unit, 2400 watts, complete . . . . .	7.50
R293	Heating wires only for R291 oven unit . . . . .	1.50
R294	Heating wires only for R292 broiler unit . . . . .	1.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 46M--Continued

Part No.	Description	List Price
----------	-------------	------------

(Electrical Parts--Continued)

R259	Oven temperature control, complete . . . . .	\$ 22.50
R266	Appliance receptacle . . . . .	1.70

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2901	Cooking top and splasher . . . . .	25.00
E2971	Switch panel . . . . .	7.00
E2902	Body side, right . . . . .	11.00
E2902	Body side, left . . . . .	11.00
E2903	Oven door panel . . . . .	4.50
E2946	Oven door lining . . . . .	3.00
E2383R	Oven lining . . . . .	10.00
E2470R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan less rack . . . . .	2.10
E2903	Front panel for utensil drawer . . . . .	4.50
E2924	Utensil drawer less front panel . . . . .	4.50
E2063	Drip pan . . . . .	2.00

(Miscellaneous Parts)

E2940	Base complete . . . . .	5.00
6651	Handle for oven and drawers . . . . .	1.50
E2973R&L	Hinge and spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for E2973 assembly . . . . .	.50
E2347	Hinge rod for oven door . . . . .	.50
E2927	Guides for utensil drawer, pair . . . . .	1.00
AG22	Rails for utensil drawer, pair . . . . .	1.00
	Chrome molding for cooking top, left or right, each	1.50
	Chrome strips for splasher, set of 3 . . . . .	1.50
	Wire oven rack . . . . .	1.00
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 56M.

Part No.	Description	List Price
----------	-------------	------------

(Electrical Parts)

R19BC	1000 watt surface unit, complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R291	Oven unit, bottom, 2000 watts, complete . . . . .	8.50
R292	Broiler unit, 2400 watts, complete . . . . .	7.50
R293	Heating wires only for R291 oven unit . . . . .	1.50
R294	Heating wires only for R292 broiler unit . . . . .	1.50
R259	Oven temperature control, complete . . . . .	22.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 56M--Continued

Part No.	Description	List Price
(Electrical Parts--Continued)		
R266	Appliance receptacle . . . . .	\$ 1.70
R182	Toggle switch for plate warmer unit . . . . .	1.00
R237	Plate warmer unit, complete before Serial W2699 . . .	10.00
R312	Plate warmer unit complete after Serial W2699 . . .	10.00

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2901	Cooking top & splasher . . . . .	25.00
E2952	Switch panel . . . . .	3.50
E2902	Body side, left . . . . .	11.00
E2902	Body side, right . . . . .	11.00
E2951	Oven door panel . . . . .	4.50
E2946	Oven door lining . . . . .	3.00
E2383R	Oven lining . . . . .	10.00
E2470R&L	Oven rack slides, each . . . . .	2.00
AE160	Broiler pan, less rack . . . . .	2.10
E2951	Front panels only, for lower right or lower left drawer . . . . .	4.50
E2923	Large drawer only less front panel, lower right . .	4.50
E2923	Large drawer only, less front panel, lower left, before Serial W2699 . . . . .	4.50
E2923-1	Large plate warmer drawer only, less front panel, after Serial W2699 . . . . .	4.50
E2954	Front panel only for small plate warmer drawer, be- fore Serial W2699 or small utensil drawer after Serial W2699 . . . . .	3.50
E2965	Small plate warmer drawer only less front panel, before Serial W2699 . . . . .	3.50
E2965-1	Small utensil drawer only, less front panel, after Serial W2699 . . . . .	3.50
E2063	Drip pan . . . . .	2.00

(Miscellaneous Parts)

E2940	Base complete . . . . .	5.00
R1872	Handle for oven and drawers . . . . .	1.50
E2973R&L	Hinge & spring assembly for oven door, complete, each	2.00
	Spring for E2973 assembly	.50
E2347	Hinge rod for oven door . . . . .	.50
E2927	Guides for warmer or utensil drawer, pair . . . . .	1.00
AG22	Rails for warmer or utensil drawer, pair . . . . .	1.00
	Chrome molding for cooking top, left or right, each	1.50
	Chrome strips for splasher, set of 3 . . . . .	1.50
	Wire oven rack . . . . .	1.00
	Aluminum broiler pan grid . . . . .	3.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 57M.

Part No.	Description	List Price
(Electrical Parts)		
R19BC	1000 watt surface unit, complete . . . . .	\$ 5.00
R158BC	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface unit . . . . .	2.50
R236	Switch (No. 49X787) for oven unit . . . . .	2.50
R289	Oven unit, bottom, 2000 watts, complete . . . . .	8.50
R290	Broiler unit, 2400 watts, complete . . . . .	7.50
R293	Heating wires only for R289 oven unit . . . . .	1.50
R294	Heating wires only for R290 broiler unit . . . . .	1.50
R259	Oven temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70
R298	Roaster temperature control, complete . . . . .	22.50
R182	Switch for Roaster . . . . .	1.00
	Roaster complete with cover, insets, and tempera- ture control . . . . .	49.50

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E3101	Cooking top and splasher . . . . .	25.00
E1677	Cover on cooking top over roaster . . . . .	4.00
R301	Cover for roaster pan, black . . . . .	4.50
E1678-1	Seal rim, black porcelain for roaster . . . . .	1.50
R264	Roaster pan . . . . .	5.00
E3102	Switch panel . . . . .	7.50
E3051	Body side, right . . . . .	11.00
E3051	Body side, left . . . . .	11.00
E2255-1	Oven door panel . . . . .	6.00
E2259-1	Oven door lining . . . . .	4.50
E2483R	Oven lining . . . . .	11.00
E2470R&L	Rack slides for oven, each . . . . .	2.20
RE160	Broiler pan less rack . . . . .	2.10
E3053	Front panel for utensil drawer . . . . .	5.00
E3067	Utensil drawer less front panel . . . . .	4.00
E3114	Drip pan . . . . .	2.00
E3054	Lower front panel . . . . .	7.00

(Miscellaneous Parts)

E2940	Base complete . . . . .	5.00
6651	Handle for oven and utensil drawer . . . . .	1.50
E2973R&L	Hinge and spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for E2973 assembly . . . . .	.50
E2299	Hinge rod for oven door . . . . .	.50
W2	Roller spring catch for oven door . . . . .	.10
E3070	Guides for utensil drawer, pair . . . . .	1.00
AG22.	Rails for utensil drawer, pair . . . . .	1.00
E1690	Food lifter, aluminum, for roaster . . . . .	1.50
	Chrome molding for cooking top . . . . .	3.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 57M--Continued

Part No.	Description	List Price
(Miscellaneous Parts -- Continued)		
	Chrome strips for splasher, set of 3 . . . . .	\$ 1.50
	Wire oven rack . . . . .	1.00
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL 73L.

Part No.	Description	List Price
(Electrical Parts)		
R2488BB	1000 watt surface unit complete . . . . .	\$ 5.00
R158BB	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R262	Combination oven temperature control and switch . . . . .	20.00
R299	Oven unit, 2000 watts, complete . . . . .	8.50
R293	Heating wires only for oven unit . . . . .	1.50
E3026	Baffle with wire frame for oven . . . . .	2.00

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E3002	Cooking top . . . . .	10.00
E3001	Splasher . . . . .	3.00
E3003	Switch panel . . . . .	3.50
E1851	Oven door panel . . . . .	6.00
E1852	Oven door lining . . . . .	4.50
E3006	Oven lining . . . . .	10.00
E3008R&L	Rack slides for oven, each . . . . .	2.20
E3028	Broiler pan less rack . . . . .	2.10
E3019	Drip pan less front strip . . . . .	1.75

(Miscellaneous Parts)

E3005	Body side, right . . . . .	5.00
E3005	Body side, left . . . . .	5.00
E3022	Base complete . . . . .	5.00
4984	Hinge for oven door, each . . . . .	.50
AE318	Spring rod for oven door, each . . . . .	.50
W2	Roller type spring catch for oven door . . . . .	.10
	Coil spring for oven door, each . . . . .	.50
E1889	Flat spring for oven door, each . . . . .	.30
AE197-4	Vent shield . . . . .	1.00
6651	Handle for oven door . . . . .	1.50
	Front strip only for drip tray . . . . .	1.50
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47M

Part No.	Description	List Price
(Electrical Parts)		
R19	1000 watt surface unit, complete . . . . .	\$ 5.00
R158	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R100 $\frac{3}{4}$	Oven unit, bottom, 1500 watts, complete . . . . .	8.50
R98 $\frac{3}{4}$	Broiler unit, 1925 watts, complete . . . . .	7.50
R293	Heating wires only for R100 $\frac{3}{4}$ oven unit . . . . .	1.50
R294	Heating wires only for R98 $\frac{3}{4}$ broiler unit . . . . .	1.50
R260	Oven temperature control, complete . . . . .	22.50
R145	Appliance receptacle . . . . .	1.50

(For additional and detailed electrical parts see)  
(pages 22 - 26. )

(Enameled Parts)

E1301-2	Cooking top . . . . .	14.00
E1101-2	Splasher . . . . .	5.50
E2825	Switch panel . . . . .	5.00
E2802L	Body side, left . . . . .	7.00
E2802R	Body side, right . . . . .	7.00
G1989-1	Oven door panel . . . . .	6.00
G1981	Oven door lining . . . . .	4.50
E1163-1L	Oven lining . . . . .	11.00
	Rack slides for oven, each . . . . .	2.20
AE160	Broiler pan less rack . . . . .	2.10
E2828	Front panel on fire door . . . . .	5.00
E2831	Lining for fire door . . . . .	3.00
E2829	Lower front panel . . . . .	5.00
	Drip tray less front strip . . . . .	2.00

(Miscellaneous Parts)

W2	Roller spring catch for oven door . . . . .	.10
E2822	Base complete . . . . .	5.00
6651	Handle for oven and fire door . . . . .	1.50
	Spring catch for fire door . . . . .	.50
G1986	Oven door hinge . . . . .	.30
G1290-2	Stake arm assembly for oven door, each . . . . .	.30
G2044	Hinge rod for oven door or stake arm . . . . .	.50
2260	Hinge for fire door . . . . .	.30
AE197-4	Vent shield . . . . .	1.00
	Front strip for dip tray . . . . .	1.50
	Wire oven rack . . . . .	.85
	Wire broiler pan rack . . . . .	.50

(Firebox Parts)

252ER	Front section, left side firebox lining . . . . .	1.00
253ER	Center section, left side firebox lining . . . . .	1.90
254ER	Rear section, left side firebox lining . . . . .	1.10
255ER	Front section, right side firebox lining . . . . .	1.10

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H47M--Continued

Part No.	Description	List Price
(Firebox Parts--Continued)		
253ER	Center section, right side firebox lining . . . . .	\$ 1.90
256ER	Rear section, right side firebox lining . . . . .	1.30
32M	Rear end lining for range with cast iron side linings and less waterfront . . . . .	1.10
32M-1	Rear end lining for range with cast iron side linings and with waterfront . . . . .	1.10
M1 LA	Firebrick lining, left front of firebox . . . . .	1.80
M1 RA	Firebrick lining, right front of firebox . . . . .	1.80
M2 RB	Firebrick lining, right back of firebox . . . . .	1.80
M2 LB	Firebrick lining, left back of firebox . . . . .	1.80
647GR	Rear end lining for range with firebricks and less waterfront . . . . .	1.00
648GR	Rear end lining for range with firebricks and with waterfront . . . . .	1.10
6B	Grate bar, long . . . . .	1.50
7B	Grate bar, short . . . . .	1.40
121D	Grate bar, long, for hard coal firebox . . . . .	1.40
122D	Grate bar, short, for hard coal firebox . . . . .	1.40
	Cogs, each . . . . .	.20
10G	Grate frame . . . . .	1.60
29D	Lid . . . . .	.90
4-30E	Short center . . . . .	1.10
68E	Anchor plate . . . . .	1.80
103D	Front end firebox lining . . . . .	.80
35D	Frame for 103D front end lining . . . . .	.80
105½D	Cog shed . . . . .	.15
20E	Clean-out door with handle . . . . .	.60
CE74-1	Back flue, steel shell only . . . . .	3.00
CE76-1	Division sheet in back flue . . . . .	1.00
90	Ash pan . . . . .	1.50
654GR	Flue damper complete with frame . . . . .	1.00
239ER	Frame for slide draft . . . . .	.50
E1491	Handle for draft slide . . . . .	.40
E1305-1	Inner front of firebox compartment, black porcelain	3.00

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H46M

Part No.	Description	List Price
(Electrical Parts)		
R248	1000 watt surface unit, complete, . . . . .	\$ 5.00
R158	1750 watt surface unit, complete . . . . .	5.50
R193	Switch (No. 49X343) for surface units . . . . .	2.50
R236	Switch (No. 49X787) for oven units . . . . .	2.50
R139	Oven unit, bottom, 1500 watts, complete, after W1422 Serial Number . . . . .	8.50
R98¾	Broiler unit, 1925 watts, complete, after W1422 Serial No. . . . .	7.50
R104	Heating wires only for R139 oven unit . . . . .	1.30

LIST PRICES OF REPAIR PARTS FOR  
MONARCH ELECTRIC RANGE MODEL H46M

Part No.	Description	List Price
(Electrical Parts--Continued)		
R252	Heating wires only for R98 <sup>9</sup> / <sub>4</sub> broiler unit . . . . .	\$ 1.50
R293	Heating wires only for R291 oven unit . . . . .	1.50
R291	Oven unit, bottom, 2000 watts complete, before Serial No. W1422 . . . . .	8.50
R292	Broiler unit, 2400 watts, complete, before W1422 Serial Number . . . . .	7.50
R294	Heating wires only for R292 broiler unit . . . . .	1.50
R261	Oven temperature control, complete . . . . .	22.50
R266	Appliance receptacle . . . . .	1.70

(For additional and detailed electrical parts)  
(see pages 22 - 26. )

(Enameled Parts)

E2851	Cooking top . . . . .	13.00
G2161	Splasher . . . . .	5.00
E2853	Switch panel . . . . .	5.00
G2166	Body side, left . . . . .	7.00
E2852	Body side, right . . . . .	7.00
E1903-1	Oven door panel . . . . .	4.50
E2316	Oven door lining . . . . .	3.00
E2383	Oven lining, before Serial Number W1422 . . . . .	10.00
E2410R	Oven lining, after Serial No. W1422 . . . . .	10.00
AE160	Broiler pan less rack . . . . .	2.10
E2855	Front panel on firedoor . . . . .	7.00
E2859	Lining for fire door . . . . .	3.00
E2856	Lower front panel below oven . . . . .	4.00
E2857	Vertical center strip . . . . .	2.00
	Drip tray, less front strip . . . . .	2.00
E791R&L	Rack slides for oven, after W1421 Serial number, each . . . . .	2.00
E2470R&L	Rack slides for oven, before W1522 Serial number, each . . . . .	2.00

(Miscellaneous Parts)

G2190	Base complete . . . . .	5.00
9140R&L	Spring assembly for oven door, complete, each . . . . .	2.00
	Spring only for 9140 assembly . . . . .	.50
E2368	Hinge rod for oven door . . . . .	.30
AE197-4	Vent shield . . . . .	1.00
	Front strip for drip tray . . . . .	1.50
	Wire oven rack, before W1422 Serial Number . . . . .	1.00
	Wire oven rack after W1422 Serial Number . . . . .	.85
	Wire broiler pan rack . . . . .	.50

(Firebox Parts)

(See H47M List of Firebox Parts)

M I S C E L L A N E O U S   E L E C T R I C A L   P A R T S

MONARCH ELECTRIC RANGES

In addition to the parts listed under each Model number, the following electrical parts are common to all L and M series ranges as indicated.

SURFACE UNITS

(1000 watt Open Coil Type)

Part No.	Description	List Price
R19	Unit complete with 9" diameter pan . . . . .	\$ 5.00
R248	Unit complete with 6½" diameter pan . . . . .	5.00
R20B	Heater brick with wires and insulating brick . . . . .	3.50
R21B	Heater brick only with wires . . . . .	2.60
R22	Wires only, 1000 watts . . . . .	1.30
R31B	Heater brick only, black, 6" diameter . . . . .	1.00
R33	Insulating brick, 6" diameter . . . . .	1.00
R73	Terminal block, 6" porcelain only . . . . .	.35
R74	Terminal block, 6" with terminal bolts . . . . .	.65
R75	Gaskets for 6" terminal block . . . . .	.20
E73C	Container ring only, 6½" diameter, chrome plated . . . . .	2.50
E73B	Container ring only, 6½" diameter, black porcelain . . . . .	1.50
E72C	Container ring only, 9" diameter, chrome plated . . . . .	2.50
E72B	Container ring only, 9" diameter, black porcelain . . . . .	1.50

(1750 watt Open Coil Type)

R158	Unit complete . . . . .	5.50
R214B	Heater brick with wires and insulating brick . . . . .	3.70
R159B	Heater brick only with wires . . . . .	2.80
R103	Wires only, 1750 watts . . . . .	1.50
R32B	Heater brick only, black, 8" diameter . . . . .	1.30
R34	Insulating brick, 8" diameter . . . . .	1.40
R70	Terminal block, 8" porcelain only . . . . .	.50
R71	Terminal block, 8" with terminal bolts . . . . .	.85
R72	Gaskets for 8" terminal block . . . . .	.20
E71C	Container ring only, 9" diameter, chrome plated . . . . .	2.50
E71B	Container ring only, 9" diameter, black porcelain . . . . .	1.50

(Parts common to both units)

R76	Brass bolts only for terminal block (3) . . . . .	.25
R65	Retaining bolts with spring washers (25) . . . . .	.50
R77	Retaining bolts for terminal block (2) . . . . .	.20

MONARCH CHROMALOX CLOSED UNITS

Part No.	Description	List Price
(Complete Units)		
CRL-6S	1000 watt single ring unit complete for 6½" range top opening . . . . .	\$ 6.90
CRL-61S	1000 watt double ring unit complete for 6½" range top opening . . . . .	7.00
CRL-6A	1000 watt single ring unit complete for 9" range top opening . . . . .	6.90
CRL-61A	1000 watt double ring unit complete for 9" range top opening . . . . .	7.00
CRL-7A	1200 watt double ring unit complete for 9" range top opening . . . . .	8.00
CRL-8A	1500 watt double ring unit complete for 9" range top opening . . . . .	8.30
CRL-9A	2000 watt double ring unit complete for 9" range top opening . . . . .	8.75
CRL-94A	2000 watt triple ring unit complete for 9" range top opening . . . . .	9.00

(Heating Rings)

R231	Single heating ring for CRL-6S and CRL-6A units . . .	4.10
R306	Outer heating ring for CRL-61A or CRL-61S . . . . .	3.00
R307	Inner heating ring for CRL-61A or CRL-61S . . . . .	2.50
R131	Outer heating ring for CRL-7A . . . . .	3.20
R132	Inner heating ring for CRL-7A . . . . .	2.70
R134	Outer heating ring for CRL-8A . . . . .	3.30
R135	Inner heating ring for CRL-8A . . . . .	2.90
R186	Outer heating ring for CRL-9A . . . . .	3.50
R187	Inner heating ring for CRL-9A . . . . .	3.25
R308	Outer heating ring for CRL-94A . . . . .	3.50
R309	Middle heating ring for CRL-94A . . . . .	3.00
R310	Inner heating ring for CRL-94A . . . . .	2.50

(Miscellaneous Parts)

Adaptor ring (specify for which unit desired) . . . . .	2.00
Reflector (specify for which unit desired) . . . . .	1.50

OVEN UNITS

Part No.	Description	List Price
(Miscellaneous Parts)		
R95	Plug complete with porcelains and contacts . . . . .	\$ 1.50
R97	Porcelains only (2) for plug . . . . .	.45
R95 $\frac{1}{2}$	Contacts only for plug (3) . . . . .	1.05
R94	Receptacle complete with porcelain and contacts . .	1.50
R96	Porcelain only for receptacle . . . . .	.85
R94 $\frac{1}{2}$	Contacts only for receptacle (3) . . . . .	.65
	Monel bolts and washers for plug, set . . . . .	.50
	Porcelain insulators for oven units (100) . . . . .	2.35

SWITCHES

Part No.	Description	List Price
(For Surface Units)		
R193	Switch complete for surface unit, (No. 49X343), three heat . . . . .	\$ 2.50
R206	Rotor assembly complete with contacts for R193 switch	1.50
R208	Set of contacts and clips only (5 sets) for R193 switch . . . . .	.50
R272	Switch complete for surface unit, (No. 78X376), five heat, to serial No. W1507 . . . . .	3.50
R272 $\frac{1}{2}$	Switch complete for surface unit, (No. 78X651), five heat, after serial No. W1507 . . . . .	3.50

(For Oven Units)

R236	Oven switch complete, preheat, bake and broil, (No. 49X787) . . . . .	2.50
------	--	------

(Switch Handles)

R215 $\frac{1}{2}$ B	Switch handle, black . . . . .	.60
R215 $\frac{1}{2}$ W	Switch handle, white . . . . .	.60

OVEN TEMPERATURE CONTROLS

Part No.	Description	List Price
(Miscellaneous Parts)		
	Dial disk with temperature markings . . . . .	\$ 1.50
	Dial knob only, specify white or black . . . . .	.75
	Bulb and bellows assembly . . . . .	5.00
	Stationary contact with studs (2) . . . . .	4.00
	Moveable contact assembly . . . . .	6.00
R241	Lamp, 7 watt, 125 volt, 1 dozen . . . . .	2.40
R241	Lamp, 7 watt, 125 volt, $\frac{1}{2}$ dozen . . . . .	1.50
R241	Lamp, 7 watt, 125 volt, 1 only . . . . .	.75
	Escutcheon plate for temperature control . . . . .	.75

## COOKERS

Part No.	Description	List Price
(3½ Qt. MONARCH Hi-Efficiency Cooker)		
R192	Cooker complete for cooking top installation . . . . .	\$16.70
R219	Cooker pail only . . . . .	3.50
R220	Cooker only, less pail and cover, for cooking top installation . . . . .	11.50
R203	Switch for cooker . . . . .	1.50
E699	Elevating ring for installing cooker on cooking top of H-type Electric Ranges . . . . .	1.25
	Pyrex cover only . . . . .	1.25
	Rack only, aluminum . . . . .	1.00
	Terminal block, specify for bottom or side . . . . .	.75

### (6 Qt. MONARCH Hi-Efficiency Cooker)

R243	Cooker complete for cooking top installation . . . . .	21.00
R243 <sup>3/4</sup>	Cooker complete for storage compartment installation . . . . .	22.50
R249	Cooker pail only, porcelain . . . . .	4.50
R250	Cooker only, less pail and cover, for cooking top installation . . . . .	15.00
R250 <sup>3/4</sup>	Cooker only, less pail and cover, for storage compartment installation . . . . .	17.50
R203	Switch for cooker . . . . .	1.50
	Pyrex cover only . . . . .	1.25
	Terminal block, specify for bottom or side . . . . .	.75
E1740	Collar for attaching cooker to under side of cooking top . . . . .	1.50

## SAUCE PAN

Part No.	Description	List Price
R269	Sauce pan complete with inset and cover . . . . .	\$16.70
R267	2½ qt. sauce pan, inset only, black enamel . . . . .	2.50
	Pyrex cover only . . . . .	1.25
	Terminal block . . . . .	.75
R311	Wires only for bottom unit brick in sauce pan, 550 watts . . . . .	.90

## PLATE WARMING UNITS

Part No.	Description	List Price
R182	Toggle switch only . . . . .	\$ 1.00
R147	Bull's eye and ring, rectangular . . . . .	.40
R156	Heating wires only, 500 watts . . . . .	.90
R241	Lamp only, 7 watt, 125 volt, each . . . . .	.75

MISCELLANEOUS PARTS

Part No.	Description	List Price
(Timer Receptacles)		
R91	Timer receptacle for replacement only . . . . .	\$ 1.25
R91 $\frac{1}{2}$	Timer receptacle with wires for range not regularly so equipped . . . . .	2.25
(Lamps)		
	Modernistic lamp, complete . . . . .	8.00
	Glass shade only . . . . .	3.00
(Shelves)		
259ER	Shelf, 11 inches long . . . . .	4.60
264ER	Shelf, 12 $\frac{1}{2}$ inches long . . . . .	4.60
(Condiment Sets)		
	2 piece, white or black, set . . . . .	1.00
	Salt or pepper shaker, white or black, each . . . . .	.60
(Timers and Notifiers)		
R303	Notifier, black or white . . . . .	6.50
R90-AS1	Electric Timer, black, for L Series . . . . .	16.65
R90-AS2	Electric Timer, white, for L Series . . . . .	16.65
R90-AS5	Combination Electric Timer and Notifier, white . . . . .	18.15